

GLUBOOST PRODUCT APPLICATION INSTRUCTIONS



GluBoost

For Build Ups Using CA Adhesive Only!

1. Apply your favorite glue.
2. Spray GluBoost from 10-12" away from the area. GluBoost will bond glue instantly.
3. Apply another layer of your favorite glue.
4. Repeat steps 1-3 until your fill is just how you want it.

For Attaching Parts Together

1. Apply your favorite glue to one of your parts.
2. Spray the other part with GluBoost.
3. Put the parts together and voila!

GluBoost Best Use Tips

Use GluBoost spray to "prep" the area and remove oil and debris before Glue or Finish application.



Fill n' Finish Thin

Use with GluBoost accelerator for super fast and clear finish and repair work.

For flexible top coats, on the spot drop fills, and effective repair of dings and dents:

1. Prepare area as you normally would.
2. Apply Fill n' Finish Thin.
3. Spray with GluBoost.
4. Use Fill n' Finish Pro Formula to fill deeper ding if needed.
5. Spray with GluBoost.
6. Wait (See Take Note! Below for drying time information.)
7. Light polish using micro mesh and or a polishing compound if desired.
8. Fnf Thin can be used for your final top coat if desired.



Fill n' Finish Pro Formula

Handle your drop fills quickly and easily with these simple instructions:

1. Clean fill area.
2. Spray drop area with GluBoost.
3. Add some Fill n' Finish Thin at the bottom of the fill area.
4. Lightly spray GluBoost in short spurts from 8" away and wait at least a couple of minutes before proceeding*.
5. Add a small amount of Fill n' Finish Pro Formula.
6. Spray GluBoost and wait a couple of minutes before proceeding. (See Take Note! Below for drying time information.)
7. Continue steps 4 and 5 until near level. Fnf Thin can be used for your final top coat if desired.

Take Note!

DRYING TIMES WILL VARY

Always allow Fill n' Finish time to dry before working or adding more product. It is always best to drop fill in small amounts at a time when using Fill n' Finish. A short spray of GluBoost before drop filling with Fill n' Finish is recommended. When using Fill n' Finish with Nitro, always spray GluBoost first before drop filling and again after filling. But in general, always wait as long as possible for Fill n' Finish to dry before working or building up your fill.

Fill n' Finish Best Use Tips

1. DO NOT REFRIGERATE OPEN BOTTLES. Doing so will create condensation that will accelerate product curing inside the bottle.
2. Remember to never touch the tip of Fill n' Finish to any area already sprayed with GluBoost.
3. Whip tips and extender tips are available, and are to be used to adjust flow and specificity for your particular job.



GLUBOOST PRODUCT APPLICATION INSTRUCTIONS



MasterGlu UltraThin

MasterGlu UltraThin Instructions

1. Prepare surface as you normally would
2. Apply MasterGlu UltraThin
3. Spray with GluBoost
4. Repeat application if needed.

Remember to never touch the tip of MasterGlu ULTRATHIN to any area already sprayed with GluBoost.



MasterGlu Thin

MasterGlu Thin Instructions

1. Prepare surface
2. Apply MasterGlu Thin
3. Spray with GluBoost
4. Repeat application if needed.

Remember: Never touch the tip of MasterGlu Thin to any area already sprayed with GluBoost.

For Attaching Parts Together

1. Apply MasterGlu UltraThin to one of your parts
2. Spray the other part with GluBoost
3. Put the parts together and voila!

Note: GluBoost works super fast!!! Once GluBoost is applied, you will only have two seconds for adjustment before it sets, so be sure you are accurate when connecting the two parts.

For Attaching Parts Together

1. Apply MasterGlu Thin to one of your parts
2. Spray the other part with GluBoost
3. Put the parts together and voila!

Note: GluBoost works super fast!!! Once GluBoost is applied, you will only have two seconds for adjustment before it sets, so be sure you are accurate when connecting the two parts.

MasterGlu Best Use Tips

DO NOT REFRIGERATE OPEN BOTTLES. Doing so will create condensation that will accelerate product curing inside the bottle.

MasterTint Vintage



MasterTint Modern



MasterTint Black & White



GENERAL MASTERTINT INSTRUCTIONS

1. Place some MasterGlu CA or Fill n' Finish onto your mixing palette.
2. Add your desired MasterTint color(s) as needed to mix and match to your finish.
3. Apply the mixed product to the work area.
4. Spray with GluBoost.
5. Work the finish to the desired sheen.
6. If the product thickens, add more MasterGlu or Fill n' Finish and continue to mix until ready to apply.

MasterTint is concentrated, and adding too much can affect drying. Multiple sprays of GluBoost may be needed for complete drying.

Important: If MasterTint has clumped, pulverize to powder before use.

MasterTint White With Another Color

1. Place some MasterGlu or Fill n' Finish on your GluBoost Mixing Palette.
2. Using a GluBoost Spatula, add your desired color to the product slowly in a mixing pattern.
3. Always break up clumps as you go along.
4. Add more color as needed to match the desired color
5. Add a second color if the desired shade requires further mix/matching.
6. If the product thickens, add more MasterGlu or Fill n' Finish and continue to mix until ready to apply.

*Note: When using white additive with another color, always add that color first, then the white.

Using White Color Alone

1. Place some MasterGlu or Fill n' Finish on your GluBoost Mixing Palette.
2. Using a GluBoost Spatula, add the white to a small amount of acetone to get to the desired opaqueness.
3. Add this mixture to your MasterGlu or Fill n' Finish.
4. If the product begins to thicken, just add more MasterGlu or Fill n' Finish.

* Alternative Method: Add the white to acetone and allow the acetone to dissolve. Then, add the residual white powder to the MasterGlu or Fill n' Finish.

MasterTint Best Use Tips

MasterTint mixes into Gluboost adhesives and finishes much more effectively in low humidity conditions. 45 percent humidity or less is best to prevent any clumping. Be sure to crush any powder tint that may have clumped/coagulated before adding it to the adhesive or finish.

