

Compatibility with Windows OS

11/15/2022

[Note]

- Please note that we have discontinued our support for any products not listed in these charts.
- We have tested all products with the latest versions as of November 2022.
- You can download the latest versions for free at <http://www.voxamps.com/support>

[Note for applications that have been released from KORG and VOX]

- These are not compatible with Modern UI.
- These are not compatible with Windows 10 Universal Windows platform (UWP).

Product Name	Windows 8.1		Windows 10 Version 21H2		Windows 10 Version 22H2		Windows 11 Version 21H2	Windows 11 Version 22H2	Remarks
	(32-bit) Support	(64-bit) Support	(32-bit) Support	(64-bit) Support	(32-bit) Support	(64-bit) Support	(64-bit) Support		
Driver									
VOX USB-MIDI Driver	Yes*1	Yes*1,*2	Yes*1	Yes*1*2	under examination	under examination	Yes*1*2	Yes*1*2	*1: Please use the latest version. *2: A 64-bit application and a 32-bit application cannot use the same MIDI IN port simultaneously.
VOX BLE-MIDI Driver	Yes*1	Yes*1	Yes*1	Yes*1	under examination	under examination	Yes*1	Yes*1	*1: Use of multiple BLE-MIDI devices or multiple MIDI applications is not supported.
VOX 2ch Audio Driver	Yes*1	Yes*1	Yes*2	Yes*2	Yes*2	Yes*2	Yes*2	Yes*2	*1: Please use VOX 2ch Audio Driver version 2.0.0. *2: Please use the latest version.
Software									
JamVOX									
- Software	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	under examination	Yes*1	Yes*1	*1: To download the latest version, you can either navigate to www.jamvox-online.com or utilize the auto-update function within the JamVOX software.
- JamVOX Monitor	Yes	Yes	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	
Tone Room	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	under examination	Yes*1	Yes*1	*1: Please install the latest version of VOX BLE-MIDI Driver when connecting with Bluetooth MIDI.
Amplifier									
ToneLab ST									
- Main Unit (USB-Audio)	Yes*1	Yes*1	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	*1: It perform in the standard USB-Audio driver. It does not work with 64-bit applications.
- Main Unit (USB-MIDI)	Yes*1	Yes*1	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	*1: You need to install the VOX USB-MIDI Driver.
- ToneLab ST ASIO Driver	Yes	No	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	
- Sound Librarian	Yes*1	Yes*1	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	*1: You need to install the VOX USB-MIDI Driver.
ToneLab EX									
- Main Unit (USB-Audio)	Yes	Yes	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	
- Main Unit (USB-MIDI)	Yes*1	Yes*1	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	*1: You need to install the VOX USB-MIDI Driver.
- ToneLab EX ASIO Driver	Yes	Yes	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	
- Sound Librarian	Yes*1	Yes*1	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	*1: You need to install the VOX USB-MIDI Driver.
VX II									
- Main Unit (USB-Audio)	Yes	Yes	under examination	Yes	under examination	under examination	Yes	Yes	
- Main Unit (USB-MIDI)	Yes	Yes	Yes	Yes	under examination	under examination	Yes	Yes	
VT20X/VT40X/VT100X									
- Main Unit (USB-MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
VX50 GTV									
- Main Unit (USB-Audio)	Yes	Yes	under examination	Yes	Yes	Yes	Yes	Yes	
- Main Unit (USB-MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
Audio GT/BS									
- Main Unit (USB-Audio)	Yes	Yes	under examination	Yes	Yes	Yes	Yes	Yes	
- Main Unit (USB-MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
Audio Air GT/BS									
- Main Unit (USB-Audio)	Yes	Yes	under examination	Yes	Yes	Yes	Yes	Yes	
- Main Unit (USB-MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
- Main Unit (Bluetooth Audio)	Yes	Yes	Yes	Yes	under examination	under examination	Yes	Yes	
- Main Unit (Bluetooth MIDI)	Yes*1,*2	Yes*1,*2	Yes*1,*2	Yes*1,*2	Yes*1,*2	Yes*1,*2	Yes*1,*2	Yes*1,*2	*1: Bluetooth low energy compatible system is required. *2: Please install the latest version of VOX BLE-MIDI Driver for Windows.
VOX Cambridge60									
- Main Unit (USB-Audio)	Yes	Yes	under examination	Yes	Yes	Yes	Yes	Yes	
- Main Unit (USB-MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
VOX MINI SUPERBEE/TLE AUDIO									
- Main Unit (Bluetooth Audio)	Yes	Yes	Yes	Yes	under examination	Yes	Yes	Yes	
Keyboard									
VOX Continental									
- Main Unit (USB-MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
Audio Interface									
amPlug iO	Yes	Yes	under examination	Yes	under examination	under examination	Yes	Yes	