Compatibility with Windows OS

7/9/2021
Note:*Please note that we have discontinued our support for any products not listed in these charts.
We have tested all products with the latest versions as of July 2021.
You can download the latest versions for free at http://www.voxamps.com/support

Note for applications that have been released from KORG and VOX:
1.These are not compatible with Modern UI.
2.These are not compatible with Windows 10 Universal Windows platform (UWP).

	Windows 8.1		Windows 10 Version 20H2		Windows 10 Version 21H1		
Product Name	(32-bit) Support	(64-bit) Support	(32-bit) Support	(64-bit) Support	(32-bit) Support	(64-bit) Support	
Driver							
VOX USB-MIDI Driver	Yes*1	Yes*1,*2	Yes*1	Yes*1*2	Yes*1	Yes*1*2	*1: Please use the latest version. *2: A 64-bit application and a 32-bit application cannot use the same MIDI IN port simultaneously.
VOX BLE-MIDI Driver	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: Use of multiple BLE-MIDI devices or multiple MIDI applications is not supported.
VOX 2ch Audio Driver	Yes*1	Yes*1	Yes*1	Yes*1	under examination*2	under examination*2	*1: Please use the latest version. *2: If you're getting audio glitches, clicks or dropouts during recording or playback via USB audio when using a supported product, please uninstall this driver.
Software							
JamVOX							
- Software	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: To download the latest version, you can either navigate to www.jamvox-online.com or utilize the auto-update function within the JamVOX software.
- JamVOX Monitor	Yes	Yes	End Of Support	End Of Support	End Of Support	End Of Support	
Tone Room	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: Please install the latest version of VOX BLE-MIDI Driver when connecting with Bluetooth MIDI.
Software							
ToneLab ST							
- Main Unit (USB-Audio)	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: It perform in the standard USB-Audio driver. It does not work with 64-bit applications.
- Main Unit (USB-MIDI)	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: You need to install the VOX USB MIDI driver.
- ToneLab ST ASIO Driver	Yes	No	End Of Support	No	Yes	No	
- Sound Librarian	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: You need to install the VOX USB MIDI driver.
ToneLab EX							
- Main Unit (USB-Audio)	Yes	Yes	Yes	Yes	Yes	Yes	
- Main Unit (USB-MIDI)	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: You need to install the VOX USB MIDI driver.
- ToneLab EX ASIO Driver	Yes	Yes	Yes*1	Yes*1	Yes*1	Yes*1	*1: It may not work in some applications.
- Sound Librarian	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: You need to install the VOX USB MIDI driver.
VX II							
- Main Unit (USB-Audio)	Yes	Yes	Yes	Yes	Yes	Yes	
- Main Unit (USB-MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	
VT20X/VT40X/VT100X							
- Main Unit (USB-MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	
VX50 GTV							
- Main Unit (USB-Audio)	Yes	Yes	Yes	Yes	Yes	Yes	
- Main Unit (USB-MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	
Adio GT/BS							
- Main Unit (USB-Audio)	Yes	Yes	Yes	Yes	Yes	Yes	
- Main Unit (USB-MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	
Adio Air GT/BS							
- Main Unit (USB-Audio)	Yes	Yes	Yes	Yes	Yes	Yes	
- Main Unit (USB-MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	
- Main Unit (Bluetooth Audio)	Yes	Yes	Yes	Yes	Yes	Yes	
- Main Unit (Bluetooth MIDI)	Yes*1,*2	Yes*1,*2	Yes*1*2	Yes*1*2	Yes*1*2	Yes*1*2	*1: Bluetooth low energy compatible system is required. *2: Please install the latest version of VOX BLE-MIDI Driver for Windows.
VOX Cambridge50							
- Main Unit (USB-Audio)	Yes	Yes	Yes	Yes	Yes	Yes	
- Main Unit (USB-MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	
VOX MINI SUPERBEETLE AUDIO							
- Main Unit (Bluetooth Audio)	Yes	Yes	Yes	Yes	Yes	Yes	
Keyboard							
VOX Continental							
- Main Unit (USB-MIDI)	Yes	Yes	Yes	Yes	under examination	under examination	
Interface							
amPlug I/O	Yes	Yes	Yes	Yes	Yes	Yes	